

OPEN FIRST!!



131 VIA CALLEJON, SAN CLEMENTE, CA 92673

Parts list for Master set # 5.18102

72-85 1/2 & 3/4 ton Standard Cab Pickup 4WD

© 2008 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front leaf spring bushing set: 5.2102 (1" eye only)

- 8 - 2029 spring bushings
- 4 - 15.10.29.39 (.625" O.D. x .500" I.D. x 2.850" sleeve)
- 1 - 17040 installation instructions

Rear leaf spring bushing set: 5.2102 (1" eye only)

- 8 - 2029 spring bushings
- 4 - 15.10.29.39 (.625" O.D. x .500" I.D. x 2.850" sleeve)
- 1 - 17040 installation instructions

Body (cab) mount set: 5.4101

- 2 - 4093 bushings (position #2, top)
- 2 - 4094 bushings (position #3, top)
- 4 - 4095 bushings (position #1, top and bottom) (.500" thk)
- 4 - 4096 bushings (position #2 & #3, bottom)
- 2 - 15.10.161.39 (.688" O.D. x .500" I.D. x 1.20" sleeve)
- 2 - 15.10.156.39 (.688" O.D. x .500" I.D. x 1.00" sleeve)
- 6 - 15.03.05.39 (2" O.D. x .500" I.D. washer)
- 4 - 15.03.28.39 (2.500" O.D. x .750" I.D. washer)
- 2 - 15.03.14.39 (2.500" O.D. x .500" I.D. washer)
- 1 - 17070 installation instructions

Tie-rod boot sets: 9.13101 (2 EA)

- 4 - 13001 tie-rod boot set

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Additional parts available for your vehicle:

Transmission mount

1972-78 vehicles with 225ci set # 5-1101

Shock boots

fits most aftermarket shocks(sold in pairs)
set # 9-8130

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

17215

14/MAR/11 BRH