

# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## MULTI-FUNCTION SOCKET WITH BACK-UP ALARM

### USCAR application



## WIRING LOCATION GUIDE

### PICKUP TRUCKS (T)

Representative vehicle shown below

T3 - Behind driver side rear bumper



## INSTALLATION / SAFETY INSTRUCTIONS

### Step 1

Locate the factory 7-way attached to the hitch, behind the center of the rear bumper in position T3 as shown in the 'Wiring Location Guide'.

### Step 2

Locate vehicle battery on the driver side under the hood and disconnect the negative battery terminal.

### Step 3

Separate the factory socket and the 7-way.

### Step 4

Insert the 57101 into the factory housing.

### Step 5

Mount the bracket to the vehicle and secure the socket.

### Step 6

Reinstall all items removed during install and reconnect negative battery terminal.

## NOTICE

All steps must be followed to ensure the CURT socket will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.