

OPEN FIRST!!

Parts list for Master set # 7-18104 91-94 Nissan Sentra



1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

© 2005 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front end control arm bushing set: 7.3109

- 4 - 2350 lower control arm bushings(front pos.)
- 2 - 15.10.135.39(.875"O.D.x.562" I.D.x2.390"sleeve)
- 2 - 3324 lower control arm bushings (rear pos.)
- 2 - 9.11108 grease
- 1 - 17253 installation instructions

Front sway bar bushing set: 7.5115

(End links included)

- 2 - 5445 28mm sway bar bushings.
(fits factory bracket).
- 2 - 8190 end link.
- 2 - 8191 end link.
- 4 - 15.03.19.39 cup washer. (1-1/4" O.D. X 10mm I.D.)
- 2 - 15.07.15.40 nylock nut. (10mm x 1.25)
- 1 - 9.11108 grease.
- 1 - 17039 installation instructions.

Rear control arm bushing set: 7.3110

- 20 - 2352 control arm bushings.
- 10 - 15.10.351.39 sleeve (.875" O.D. X .562" I.D. X 1.575")
- 4 - 2351 trailing arm bushings.
- 2 - 15.10.224.39 sleeve (.750"O.D. X 12mm I.D. X 2.225")
- 2 - 9.11101 grease.
- 1 - 17073 installation instructions.

Shifter bushing set: 7.1103

- 2 - 2278 shifter bushing.
- 1 - 15.10.278.39 sleeve (.625"O.D. X 10mm I.D x 1.000")

Front tie rod boot set: 9.13101

- 2 - 13001 tie rod boots.

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Ree sway bar bushing set: 7.5116 (End links included)

- 2 - 5117 15mm sway bar bushings.
- 2 - 15.08.02.39 bracket.
- 8 - 15.03.69.39 flat washer (.813"O.D. X 10mm I.D.)
- 2 - 8190 end link.
- 2 - 8191 end link.
- 4 - 15.05.47.39 bolt (10mm x 1.25 x 25mm)
- 4 - 15.03.19.39 cup washer. (1-1/4" O.D. X 10mm I.D.)
- 4 - 15.07.15.40 nylock nut. (10mm x 1.25)
- 1 - 9.11108 grease.
- 1 - 17039 installation instructions.

Additional parts available for your vehicle:

Motor mount insert set: (manual trans only)

- 7.1105
- 7.1106

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

17294

21/AUG/14 BRH